



Supplies to make a hoop with screw off feet;

1. PVC pipe 20mm
2. Poly pipe 19mm
3. 20mm pvc end cap x 2
4. 20mm 4 way tee x 1
5. 20mm 80 degree elbow x 1
6. 20mm PVC Valve socket x 2
7. 20mm PVC Valve take off
8. PVC cement
9. Pipe cutter tool or hacksaw

Hoop frame is made of;

PVC base of 34 inch piece of 20mm PVC pipe on one end the 90 degree elbow is cemented on and the other end the 4 way tee.

The uprights are 2x 16 inch long 20mm PVC pipe. They are cemented in to the base to form the uprights.

The hoop arch is made from a 92 inch long piece of 19mm polypipe which can then be slotted into the uprights - push it all the way to the base (no need to glue in place)

You will need to cut and glue a 2 inch piece of 20mm pvc pipe into the remaining openings of the 4 way Tee. Then glue the no threaded end of the Valve take off onto the end of these.

The screw in feet are made of;

2 lengths of 8 inch 20mm pvc pipe. On the end of each 8 inch length glue an end cap on one end and a valve socket on the other end.

